



## INSTRUCTIONS



Center the dot for the perfect shot!

**STOP** STOP!!!! DO NOT ADJUST ANY OF THE RETINA LOCK ADJUSTMENTS!!!

*IQ Ultra Lite Bowsight™ set up instructions:*


### Step 1: Mounting Sight To Bow

Mount the sight onto your bow with the bow mounting screws provided.



### Step 2: Top Pin Adjustment


Set your top pin to your preferred position in the bezel using the hex key provided. (we recommend in the top 1/3 of the bezel)  
Sight in your first pin at your preferred distance (we recommend 20 yards).



**STOP** Before beginning Step 3 make sure your top pin is sighted in.

### Step 3: Retina Lock™ Adjustment


Once your top pin is accurately sighted in – it's time to adjust your Retina Lock™. Draw your bow using the same form/anchor point used to set your top pin and look for the green Retina Lock™.



### Retina Lock™ Adjustment

a) If you see the green Retina Lock™, adjust the green Retina Lock™ until the black dot is centered within the green Retina Lock™ using the micro adjustments located on the top and top side of sight. Remember you are adjusting the green Retina Lock™ to fit your form/anchor point. Repeat this step until the black dot is centered in the green Retina Lock™ – at your form/anchor point.

Left & Right      Up & Down



b) If you don't see the green Retina Lock™ at your form/anchor point you will need to move your anchor point up or down and possibly left or right until you find the green Retina Lock™. Once you've determined the direction of the green Retina Lock™, use the micro adjustments located on the top and top side of sight to adjust the green Retina Lock™ to fit your form/anchor point. The micro adjustment on the top of the sight is to move the green Retina Lock™ up and down and the micro adjustment on the top side of sight is to move the green Retina Lock™ left and right – **REMEMBER YOU ARE MOVING THE GREEN Retina Lock™**. Repeat this step until the black dot is centered in the green Retina Lock™ – at your form/anchor point.

#### HOW TO ADJUST:

If the green Retina Lock™ is high and to the right, you will need to move the adjustment low and to the left to try and

center the black dot in the green Retina Lock™ at your form/anchor point. Repeat process as needed. Once your black dot is centered in the green Retina Lock™ **AT YOUR FORM/ANCHOR POINT** it's time to sight in the rest of your pins!

CENTER THE DOT FOR THE PERFECT SHOT!



If you tourge your bow 1/4" and the pin is on  
**Shot Is Off!**  
5" Off at 20 yards  
10" Off at 40 yards

If your anchor point is 1/4" low and the pin is on  
**Shot Is Off!**  
5" Off at 20 yards  
10" Off at 40 yards

If you center the black dot and your pin is on  
**Perfect Shot!**

For a quick video on how to set up your IQ Ultra Lite Bowsight™ please visit:  
[iqbowsights.com](http://iqbowsights.com)


# IQ

## ULTRA LITE BOWSIGHT

RETINA LOCK™

For more info visit: [iqbowsights.com](http://iqbowsights.com)

### Parts Included:



Dual Position Mount

Lightweight  
Fiber Polymer  
Construction

- High Impact Resistant
- Silent Coat Finish

Stack Tight  
.019 Pins

Elevation & Windage  
Adjustment

No Batteries!  
Legal in all states

Retina Lock™  
Technology



## Revolutionary Retina Lock Alignment Technology –

Provides instant feedback that will identify even the slightest torque or anchor point change