



# OZONE GO MAX OPERATION

Plug the unit into the vehicle electronic outlet to work. The orange LED light indicates that the unit is receiving power and ozone is being released.

The ozone generator will run for 30 minutes over an initial 50-minute period, cycling on and off in 10-minute intervals. After the initial 50-minute cycle is complete, simply remove the unit and re-insert to restart the cycle.

Branchez l'appareil dans la prise électronique du véhicule pour qu'il fonctionne. Le voyant DEL orange indique que l'unité est alimentée et que de l'ozone est libéré.

Le générateur d'ozone fonctionnera pendant 30 minutes sur une période initiale de 50 minutes, en se mettant en marche et en arrêtant par intervalles de 10 minutes. Une fois le cycle initial de 50 minutes terminé, retirez simplement l'unité et réinsérez-la pour redémarrer le cycle.